



# prep*FAST* PPQ

# **Automated Sample Preparation and Introduction System for PPQ Metals Determination in High Purity Chemicals**

The prepFAST PPQ is the most advanced tool for analyzing ultrapure semiconductor grade chemicals with ICPMS detection. The prepFAST PPQ utilizes syringe-driven flows of UPW, semiconductor grade acids, and standard solution to automate both sample dilutions and standard curve generation. It eliminates manual handling of samples to deliver sub-ppq detection limit capabilities in concentration mode and sub-ppt detection limit capabilities in direct analysis mode.

#### **Two High Purity Modes**

#### **Direct Analysis Mode**

- Capability to analyze all semiconductor grade chemicals
- Sub-PPT detection limits for all semiconductor elements
- General purpose for any sample matrix
- Automated MSA calibration
- Automated inline dilution

#### **Concentration Mode**

- Suitable for UPW, 30% H<sub>2</sub>O<sub>2</sub>, and IPA
- Sub-PPQ detection limits
- Removes difficult matrices such as IPA while recovering metals
- Removes impact of ICPMS interferences and backgrounds on results
- Amplified sensitivity compared to direct analysis
- Automated MSA calibration

#### prepFAST PPQ Autocalibration

The prep*FAST* PPQ automatically prepares calibration curves for over 40 elements controlled in semiconductor manufacturing processes. Calibrations are generated by automatically diluting an enclosed multielement stock standard. Automation with the high-purity prep*FAST* PPQ achieves low to sub-ppt calibrations in direct analysis mode and low ppq calibrations in concentration mode.



prep*FAST* PPQ System

### **High Purity Automation with PPT/PPQ results**

#### **Automation**


- Automatic external and MSA calibrations
- Automated sample sensing
  - Accounts for viscosity and automatically adjusts timing
  - Detects and injects the sample and triggers the ICPMS
- Automated syringe-driven sample introduction
  - Sample loading
  - Sample preparation
  - Inline dilution
  - Acid addition (direct mode only)

#### **Ultraclean**


- Ultraclean sample preparation
- Integrated ultraclean sample environment
  - · Includes ultraclean air shower
  - Sample racks for PFA containers (<1 mL to 500 mL)
- Continuously-flowing high purity UPW rinse (user-supplied UPW)
- UPW polishing columns for low background

prep <i>FAST</i> PPQ System						
System	Integrated Mobile Autosampler & Enclosure	Ultraclean Air Shower	Integrated FAST valve modules	PFA Nebulizer with Integrated Capillary	PFA Sample Probes	Syringe Pump S500V2
prep <i>FAST</i> PPQ	<b>✓</b>	$\checkmark$	<b>√</b>	<b>✓</b>	<b>√</b>	<b>√</b>

# **Pure Automation**



### prepFAST PPQ Inline Dilution of Semiconductor-grade Chemicals



The prepFAST PPQ allows dilution by volume or weight for IPA and H<sub>2</sub>O<sub>2</sub> in concentration mode, and all semiconductorgrade chemicals in direct analysis mode. Metals are quantified using automated inline MSA or external calibration. Automated direct analysis of concentrated chemicals eliminates sample contamination caused by manual dilution into a secondary container.

Diagram showing 10x inline dilution of concentrated  $H_2SO_4$  with prepFAST PPQ.

Examples of Semiconductor Chemicals Analyzed at the ppt Level with prep <i>FAST</i> PPQ*						
Acids	98% H <sub>2</sub> SO <sub>4</sub>	89% H <sub>3</sub> PO <sub>4</sub>	70% HNO <sub>3</sub>	49% HF	35% HCI	30% H <sub>2</sub> O <sub>2</sub>
Bases	22% NH <sub>4</sub> OH	2.38% TMAH	25%TMAH	KOH		
Organics	IPA	PGMEA/PGME	Photoresist	NMP	Butyl Acetate	Cyclohexanone

<sup>\*</sup>This table contains only a partial list of chemicals which can be analyzed using prepFAST PPQ in direct analysis mode.

## **Concentration Mode**


### **Sampling Options in Concentration Mode**

#### **Direct sample modules**

- Availability to monitor up to four pressurized sample lines
- Flushing and sampling processes are controlled by an all-fluoropolymer valve manifold

#### **Enclosed bottle samples**

- Rack with integrated probes and caps to keep bottled samples fully enclosed before and during sampling
- Can accomodate up to 2L bottles
- Automated UPW probe rinse between samples



Layout of four 1L enclosed bottle samples to the left of the autosampler.

# Example of Detection Limits in Non-cleanroom Environment in Concentration Mode (1000x Concentration Factor)


Element	DL <b>(PPQ)</b>	Element	DL <b>(PPQ)</b>
<sup>7</sup> Li	0.02	<sup>85</sup> Rb	0.01
<sup>11</sup> B	9	<sup>88</sup> Sr	0.06
<sup>23</sup> Na	0.6	<sup>90</sup> Zr	0.1
<sup>24</sup> Mg	0.2	<sup>93</sup> Nb	0.2
<sup>27</sup> AI	0.6	<sup>98</sup> Mo	0.3
<sup>28</sup> Si	240	<sup>75</sup> As	0.2
<sup>39</sup> K	0.4	<sup>107</sup> Ag	0.05
<sup>40</sup> Ca	0.3	<sup>114</sup> Cd	0.06
<sup>42</sup> P	2	<sup>115</sup> <b>In</b>	0.01
<sup>48</sup> Ti	0.2	<sup>118</sup> Sn	0.5
<sup>51</sup> <b>V</b>	0.7	<sup>121</sup> Sb	0.4
<sup>52</sup> Cr	0.4	<sup>133</sup> Cs	0.007
<sup>55</sup> Mn	0.07	<sup>138</sup> Ba	0.04
<sup>56</sup> Fe	0.3	<sup>180</sup> Hf	0.2
<sup>58</sup> <b>N</b> i	0.07	<sup>181</sup> Ta	0.3
<sup>59</sup> Co	0.01	<sup>184</sup> <b>W</b>	0.4
<sup>63</sup> Cu	0.07	<sup>195</sup> Pt	0.1
<sup>64</sup> Zn	0.4	<sup>205</sup> TI	0.03
<sup>69</sup> Ga	0.004	<sup>208</sup> Pb	0.05
<sup>74</sup> Ge	0.6	<sup>106</sup> Pd	0.4


## **Concentration Mode**

#### prepFAST PPQ Autocalibration


Autocalibrations for elements controlled in semiconductor manufacturing processes are generated by automatically diluting an enclosed multielement stock standard. Automation with the high-purity prep*FAST* PPQ achieves ppt to sub-ppt calibration in direct analysis mode and ppq calibrations in concentration mode.


#### **UPW Autocalibration in Concentration Mode**





### **UPW Autocalibration in Concentration Mode**







# Direct Analysis Mode

Example of Detection Limits in Non-cleanroom Environment in Direct Analysis Mode				
Element	DL (ppt)	Element	DL (ppt)	
<sup>7</sup> Li	0.02	<sup>72</sup> Ge	0.04	
<sup>9</sup> Be	0.007	<sup>75</sup> As	0.2	
<sup>11</sup> B	0.9	<sup>85</sup> Rb	0.008	
<sup>23</sup> Na	0.07	<sup>88</sup> Sr	0.008	
<sup>24</sup> Mg	0.01	<sup>90</sup> Zr	0.004	
<sup>27</sup> AI	0.03	<sup>93</sup> Nb	0.002	
<sup>39</sup> K	0.06	<sup>95</sup> Mo	0.5	
<sup>40</sup> Ca	0.4	<sup>111</sup> Cd	0.07	
<sup>48</sup> Ti	0.02	<sup>115</sup> ln	0.004	
<sup>51</sup> <b>V</b>	0.1	<sup>118</sup> Sn	0.05	
<sup>52</sup> Cr	0.1	<sup>121</sup> Sb	0.05	
<sup>55</sup> Mn	0.009	<sup>137</sup> Ba	0.04	
<sup>56</sup> Fe	0.04	<sup>178</sup> <b>Hf</b>	0.003	
<sup>58</sup> Ni	0.01	<sup>181</sup> <b>Ta</b>	0.01	
<sup>59</sup> Co	0.007	<sup>182</sup> <b>W</b>	0.01	
<sup>60</sup> Ni	0.01	<sup>205</sup> TI	0.002	
<sup>63</sup> Cu	0.03	<sup>208</sup> Pb	0.005	
<sup>64</sup> Zn	0.04	<sup>232</sup> Th	0.000	
<sup>71</sup> Ga	0.002	<sup>238</sup> U	0.003	

# Direct Analysis Mode

### **Autocalibration in Direct Analysis Mode**











## **Elemental Scientific**

www.icpms.com

© Elemental Scientific | +1 402-991-7800 | sales@icpms.com | 7277 World Communications Drive | Omaha, NE 68122